Experimental geometries suggested by the lave condition

An incident wave vector is will lead to a Bragg peak if and only if the top of the wave vectors lies on the a K-space Briagg plane. Now, the set of all briagg planes is a discrete and of family of planes. These are the planes found by the bisecting the or vectors w.r.t. an origin in the G-space with a perpendicular plane. So, the Bragg planes will not fill up the 30 # space and in general the tip of R will not be on a Breagg plane. Thus, for a fixed incident wave vector, that is, for a fixed X-ray wavelength and fixed incident direction. relative to the crystal arer, there will be no Bragg peak at all in general. If one wishes to search experimentally for the Brzagg peaks, one must relax the condition of fixed it, either by varying the magnitude of it (charging the wavelength) on by varying it's direction, which in

Practice is obtained by varying the orientation of the crystal with respect to the incident direction.

The Ewald construction

Ewald construction is a simple geometric construction that is of great that help in visualizing various methods and to observe the Bragg peaks and in deducing the crystal structure from the observed peaks.

He draw Consider the Lave condition. We have the incident wave-vector \vec{k} originating from a point of and scattered wave vector \vec{k}' . Also, $\vec{G}_1 = \vec{k} - \vec{k}'$ which also, say oroginate at 0. Now, \vec{G}_1 must be which also, say oroginate at 0. Now, \vec{G}_2 must be a neciprocal lattice vector, meaning a vector in the reciprocal space. We draw.

 $K = \frac{2\pi}{\lambda}$, which means the point 0 will be on the surface of the ophere. This is is the Ewald sphere. Now, Since it and it has the same magnitude, k' must also be the readium of the Ewald sphere, and so it's tail must be on the swiface of the sphere. What it means is that, the scattered wave vector R' will satisfy the Laue condition if and only if the reciprocal lattice vector of ends on the surface of the Ewald sphere, meaning, it and only if the reciprocal lattice point is on the surface of the Ewald sphere. In that case, there will be a Bragg reflection from the family of direct lattice planer perpendicular to Gi.

In general, a ophere in k-space with the origin of k-space on it's surface might have no other reciprocal lattice points on it's surface, and for a general neident wave-vector there will be no Bragg peak. One can, however, ensure that some Bragg peaks will one produced by several techniques, some of which be described here.

1. The Lave method! One can continue to scatter from a single crystal of fixed ordentation from a fixed incident dirrection n, but can search for Bragg peaks by not using a monochromatic X-ray beam, but a bean containing wavelengths from 2, to 20, corrresponding to wave-vectors $\vec{k} = 2\pi \hat{n}$ and $\vec{k} = \frac{2\pi}{\lambda_0} \hat{n}$. We will be now able to form many Ewald other, and to be specific, the Ewald sphere will now expand into the region contained between the two opheres determined by \vec{k}_0 and \vec{k}_N . The Bragg peaks will Then be observed if a reciprocal lattice vector lies in this region. If course we are talking about a continuous range of wave. length from he to he making the spread in wavelength sufficiently large, one can be sure of finding some reciprocal lattice points within this region. Also, the spread shouldn't be very large, because then there will be too many broagg peans, and the picture won't be will get

congested.

2. The rotating crystal method: This method uses a monochromatic X-ray, but allows the angle of incidence to vary. This is done by not changing the direction of the X-ray, but the orcientation of the X-ray is varied instead In the restating crystal method the crystal is rotated about a fixed axis, and the Briagg peaks that occurs during the 170tation is one recorded on a seneer film. As the anystal notates, the neciprocal lattice that the direct lattice determines will rotate about the same axis as well. Thus, the Ewold where in fixed in the K-space (since it is determined by the incident wave-vector is that

is not changing), while
the whole crystal rotates
about the axis of rotation of the crystal. During
the rotation process, each reciprocal lattice point

traverses a circle in the reciprocal space about the rotation axis, and a Bragg peak occurs whenever the circle intersects the Ewall sphere (meaning the reciprocal lattice point lies on the surface of the sphere at that time).

3. The powder on Debye-Schoner method: This is equivalent to the notating anystal method, except the axis of rotation is varied over all possible orcientations. For this it is not necessary to notate the anystal itself. Rather, this is achieved by taking the powed powder of a crystal sample grains of which are still enormous on the atomic scale and therefore capable of diffracting X-rays. Because the argstal axes of individual grains is randomly ordented the diffraction patteren produced by such a powder is what one would expect to be produced by combining the diffraction pattern of all possible ordentation in a single crystal.

The Broad & peaks are now determined by fixing the incident wave-vector \vec{x} , and with it the

Ewald sphere as well, and then allowing the reciprocal lattice to notate through all possible angles about the origin, so that the reciprocal lattice vector & & generales a ophere of radius Co about the origin. The vector joining Such & a sphere will intersect the Ewald sphere in a circle, provided that & G is less than &x (if G) QK, the ophere with radius G will Just enclose the Ewald sphere with readius k, without intersecting). The rector joining any point on the circle to the tip of R will be as a noca-Hered wave-vector it for which Briagg peaks will be observed. The figure here shows a plane section of the two intersecting spheres. Each neciprocal lattice vector with practe less than ex will make a cone of scattered nadiation at an angle ϕ in the forward direction. (see the figure in Ashoroff and Mormin in page 103). Since 20PB in isoscele, $\angle POQ = \angle OPQ = 4 \frac{180^{\circ} - \varphi}{2} = \frac{17 - \varphi}{2}$

Now, using the sine rule,

$$\frac{K}{\sin(\frac{\pi}{2} - \frac{\Phi}{2})} = \frac{G_1}{\sin \Phi}$$

$$\Rightarrow G_1 = \frac{K \times \sin \Phi}{\cos \Phi_2} = \frac{K \times 2 \sin \Phi}{\cos \Phi_2} \cos \Phi_2$$

$$\therefore G_1 = 2K \sin \Phi_2$$

By measuring the argles of at which the Bragg peaks occurs are observed, one then therefore learns about the lengths of all reciprocal vectors shorter than ex. Armed with this information, along with knowing some facts, about the crystal symmetry, and the fact that reciprocal lattice is a Bravais lattice, one can usually construct the reciprocal lattice itself.